



## Remote Controlled Inductive Rechargeable LED Lamp

**Includes:** (12) Rechargeable EcoLytes™ Remote LED Lamps, (1) Charging Base & Power Supply, (1) Handheld Remote Controller per set.

**Input Voltage:** 100-240 volts **Operating Voltage:** 12VDC

### Charging Instructions:

1. Leave the Charger Base plugged into the power source continuously.
2. Candles should be "Off" when charging.
3. Charge time is approximately 8 hours.
4. Candles are recommended for indoor use. They are not waterproof.
5. Turn "Off" lamp power button when not being used longer than 3 days.

### Remote Control Operation:

- **On** – Turns on the Lamps LED, recalls last operating mode. (an unlimited number of LED Lamps can be used)
- **Off** – Turns off the Lamps LED from any mode. (LED Lamp still uses battery power and is still operating when in "Off" mode)
- **4H or 8H** – Will automatically turn off the LED Lamps after 4 or 8 hours respectively. Press 4H or 8H instead of the On button to activate timer mode.
- **Candle Mode** – Pauses the flickering effect.
- **Light Mode** – Starts the flickering effect. (best used after selecting dim or bright)
- **Dim** – Sets the light level. (allows the maximum operating time)
- **Bright** – Sets the light level.

### Important:

Failure to follow these instructions will void the manufacturer's warranty.

1. Candles must be charged before use.
2. Only use power supply provided with the system. Using another power supply will permanently damage the base.
3. EcoLytes™ is designed to link a maximum of two (2) charging bases together using one 12V1A power supply or link a maximum of four (4) charging bases together using one 12V2A power supply.
4. If the EcoLytes™ are not going to be used for more than 4 weeks, fully charge the candles and make sure the button is in the OFF position. During long term storage, candles should be charged and discharged once every 6 months.
5. Once every three (3) months, charge the candles 2 complete charging cycles, to re-activate the rechargeable batteries built into the system. Always fully charge the candles when using for the first time or after an extended period of non-use.
6. Do not subject the candles to adverse conditions such as extreme temperature, or excessive over-charge/discharge. Do not incinerate or mutilate the candles as the rechargeable batteries may burst or release toxic materials.
7. Store the EcoLytes™ System in a cool dry area.
8. Do not submerge or place the candles or charging base into water.
9. Candles are recommended for indoor use. They are not waterproof.
10. Cleaning instructions: wipe candles and base with a clean slightly damp cloth. Make sure the charging base is unplugged from electrical outlet before cleaning.