



Remote Controlled Inductive Rechargeable LED Lamp V4

Includes: (12) Rechargeable EcoLytesFX™ LED Lamps, (1) Charging Base & Power Supply, (1) Handheld Remote Controller per set.



Input Voltage: 100-240 volts **Operating Voltage:** 12VDC

Charging Instructions:

1. Leave the Charger Base plugged into the power source continuously.
2. Candles should be "Off" when charging.
3. Charge time is approximately 8 hours.
4. Candles are recommended for indoor use. They are not waterproof.
5. Turn "Off" lamp power button when not being used longer than 3 days.

Remote Control Operation:

Default mode with Power switch is medium white flickering.

- **On** – Turns on the Lamps LED, recalls last operating mode and color. (an unlimited number of LED Lamps can be used)
- **Off** – Turns off the Lamps LED from any mode. (LED Lamp still uses battery power and is still operating when in "Off" mode)
- **Off Timer 4Hr** will automatically turn off the LED Lamps after 4 hours. Press Timer 4H instead of the On button to activate timer mode.
- **Dim**  Sets the low light level when in Candle mode only. (allows the maximum operating time)
- **Bright**  Sets the highest brightness light level in Candle mode only.
- **Smooth** – Rotates through the 12-color pallet in a slow 30 second transition period.
- **Flash** – Rotates through the 12-color pallet in 3 modes; Slow 30 second period, Off, Fast with a 2 speed random pattern.
- **Candle**—Selects the realistic flickering candle mode for any color.
- **Light**—Selects a steady non-changing light.
- **Color Buttons** – Selects predetermined individual colors with one button press.

Important: Failure to follow these instructions will void the manufacturer's warranty.

1. Candles must be charged before use.
2. Only use power supply provided with the system. Using another power supply will permanently damage the base.
3. If the EcoLytesFX™ are not going to be used for more than 4 weeks, fully charge the candles and make sure the button is in the OFF position. During long term storage, candles should be charged and discharged once every 6 months.
4. Once every three (3) months, charge the candles 2 complete charging cycles, to reactivate the rechargeable batteries built into the system. Always fully charge the candles when using for the first time or after an extended period of non-use.
5. Do not subject the candles to adverse conditions such as extreme temperature, or excessive overcharge/discharge. Do not incinerate or mutilate the candles as the batteries may burst or release toxic materials.
6. Store the EcoLytesFX™ System in a cool dry area.
7. Do not submerge or place the candles or charging base into water.
8. Candles are recommended for indoor use. They are not waterproof.
9. Cleaning instructions: wipe candles and base with a clean slightly damp cloth. Make sure the charging base is unplugged from electrical outlet before cleaning.