

# *Easy Ambience Remote* Low Voltage Wired Installation Instructions

## **Includes:**

(12—96) Rechargeable *Easy Ambience*™ Candle Lamps  
(1) Junction Box & Power Supply  
(1) Handheld Remote Controller per set.  
T-Tap Connectors  
Spade Terminals  
18 Ga. Zip Cord

**Input Voltage:** 100-240 volts **Operating Voltage:** 4.5VDC

## **Remote Control Operation:**

- **On** – Turns on the Lamps LED, recalls last operating mode. (an unlimited number of LED Lamps can be used)
- **Off** – Turns off the Lamps LED from any mode. (LED Lamp still uses battery power and is still operating when in "Off" mode)
- **4H or 8H** – Will automatically turn off the LED Lamps after 4 or 8 hours respectively. Press 4H or 8H instead of the On button to activate timer mode.
- **Candle Mode** – Pauses the flickering effect.
- **Light Mode** – Starts the flickering effect. (best used after selecting dim or bright)
- **Dim** – Sets the light level. (allows the maximum operating time)
- **Bright** – Sets the light level.

**Important:** Failure to follow these instructions will void the manufacturer's warranty.

1. Only use the power supply provided with the system. Using another power supply may permanently damage the candles.
2. Do NOT connect more than 96 candles per Junction Box.
3. Do not submerge or place the candles into water.
4. Candles are recommended for indoor use. They are not waterproof.