

Lounge Lamps

Remote Controlled Inductive Rechargeable LED Lamp

Includes: (2) Rechargeable LED Lamps, (1) Dual Charging Base & Power Supply, (1) Handheld Remote Controller per set.

Input Voltage: 100-240 volts **Operating Voltage:** 5VDC

Charging Instructions:

1. Insert the adaptor plug to the charging tray. Plug the adaptor to AC power.
2. Leave the Charger Base plugged into the power source continuously.
3. Candles should be "Off" when charging.
4. The Charging indicator on each candle illuminates constant Red when powered. The indicators will flash Green with lamps on the charging tray. The indicator will stop flashing Green and stay on when fully charged. Charge time is approximately 5 hours.
5. Charging Trays can be linked together with a connection cable. (Note: Tray Connecting Cables are not included with set and are purchased separately).
6. One 5V 2A adaptor can charge up to 2 trays (4 Lamps) at the same time. (Included)
7. One 5V 4A adaptor can charge up to 4 trays (8 Lamps) at the same time.
8. The lamp power button allows basic on/off and 12 color selection without the remote.

Remote Control Operation:

(an unlimited number of LED Lamps can be used)

On – Turns on the Lamps LED, recalls last operating mode and color.

Off – Turns off the Lamps LED from any mode. (LED Lamp still uses standby battery power and is still operating when in "Off" mode)

Dim – Allows 4 dimming levels.

Bright – Allows 4 brightness levels.

Flash – Rotates through the 16-color pallet in 1 second increments.

Strobe - Rotates through the 16-color pallet in 3 second increments.

Fade - Rotates through the 108 step color pallet in a slow 2 minute transition period.

Smooth – Will alternately move between Smoothly Rotation through the 12-color pallet over 30 second minute transition period then through the Flash Mode.

Color Buttons – Selects predetermined individual colors with one button press.



Important: Failure to follow these instructions will void the manufacturer's warranty.

1. Lamps must be charged before use.
2. Only use power supply provided with the system. Using another power supply will permanently damage the base.
3. If the Lounge Lights™ are not going to be used for more than 4 weeks, fully charge the candles and make sure the button is in the OFF position. During long term storage, lamps should be charged and discharged once every 6 months.
4. Once every three (3) months, charge the lamps 2 complete charging cycles, to re-activate the rechargeable batteries built into the system. Always fully charge the lamps when using for the first time or after an extended period of non-use.
5. Do not subject the lamps to adverse conditions such as extreme temperature. Do not incinerate or mutilate the lamps as the batteries may burst or release toxic materials.
6. Store the Lounge Lights™ System in a cool dry area.
7. Do not submerge or place the lamps or charging base into water.
8. Cleaning instructions: wipe candles and base with a clean slightly damp cloth. Make sure the charging base is unplugged from electrical outlet before cleaning.